0080T0T "6ht9T6960



FIGURE 1

006T0T" ch9T6960



FIGURE 2


to/from Router
To/from computer Ethernet Card
36
38
Power Module
INTERFACE
20
Administration Module 32
Security Module 34
Tamper Module 42
Config Data 40
LOCAL FIREWALL

FIGURE 3


Begin
Receive Power
400
Retrieve configuration data from policy server
402
Retrieve default data
404
configure
406
408
modifications?
NO
yes
Modify as specified
410
end

FIGURE 4